


# PYNQ-Getting Started:

## Agenda

- Configure board
- Connect to the board
- Login in to portal
- Jupyter notebook

## Prerequisites for running the labs:

- PYNQ-Z1 board
- PYNQ v2.2 image for the PYNQ-Z1 board
- HDMI cables, ethernet cable, webcam



Download and prepare SD card: <http://www.pynq.io/board.html>

Download PYNQ Image for Board and load image via win32 diskImager.


## Connecting to the board:

- Configure board to boot from SD Card
- Set jumper to power
- Insert SD Card
- Connect USB Cable
- Connect ethernet cable
- Power on



## Login in to Jupyter portal:


- Open browser
- Browse to: `http://10.10.10.###:9090` (IP) or <http://pynq:9090>
- Password: xilinx



## Getting started with Jupyter Notebook

- Jupyter notebook: web application/server
- Create and share documents (live code, equations, text, results)
- Writing text with markdown and heading
- Writing and running Python scripts

## Jupyter notebook cells:



- code: PYTHON
- Markdown: Comments and notes
- Execute cells to run code
- Output printed after cell

```
In [14]: from PIL import Image as PIL_Image

orig_img_path = '/home/xilinx/jupyter_notebooks/Examples/data/webcam.jpg'
!fswebcam --no-banner --save {orig_img_path} -d /dev/video0 2> /dev/null

img = PIL_Image.open(orig_img_path)
img
```



## Documents:

### Documentation

<https://pynq.readthedocs.io>

### Accessible from

<http://www.pynq.io>

### support

<http://www.pynq.io/support>

### Github

<https://github.com/Xilinx/PYNQ>